

Installation Instructions

Nicenza vicenza

Installation Instructions:

- 1. Disassemble the rear hub by inserting a 5mm allen key in both side of the axle, and turning opposite each other (standard right-hand threads).
- 2. Unthread and remove the left hand end cap.
- Slide the free hub body and hollow axle together out of the main hub shell.Note: Be sure to remove the inner shim which is located inside the free body
- 4. Losen the lock ring and Slide off the black spacer from hub shell , Please keep the metal spacer on thread section of hub shell.

PRO-LITE

Side Cover

Long

Sleeve

Anti slip Nut

T type nut

5. Undo all parts from assembled track axle kit.

Track Hub

spacer

Spocket

Lock Ring

Anti slip Nut

T type nut

- 6. Insert the Track slide axle into the road drive side of the hub.
- 7. Reassembly the Track axle kit as following drawing (3)
- 8. Keep the metal spacer between sprocket and hub shell
- 9. Tighten down the T type nut and fasten the anti-slip lock nut .

