

## PRO-LITE

## Installation Instructions:

- 1. Disassemble the rear hub by inserting a 5mm allen key in both side of the axle, and turning opposite each other (standard right-hand threads).
- 2. Unthread and remove the left hand end cap.
- 3. Slide the free hub body and hollow axle together out of the main hub shell Note: Be sure to remove the inner shim which is located inside the free body
- 4. Losen the lock ring and Slide off the black spacer from hub shell, Please keep the metal spacer on thread section of hub shell.
- 5. Undo all parts from assembled track axle kit.
- 6. Insert the Track slide axle into the road drive side of the hub.
- 7. Reassembly the Track axle kit as following drawing (3)



2 in 1 Hub Disc Wheel





